




Press the control board code matching button twice in a row, wait for the LED indicator light to turn off, and then press the remote control A button that requires code matching. The control board LED indicator light will flash continuously for three times. The A button successfully matches the code, and the indicator light will go out to enter the second button learning state. At this time, press the remote control B button, and the control board LED indicator light will flash continuously for three times. The B button successfully matches the code, and the indicator light will stay on for a long time. The code matching is completed.

The remote control can be equipped with low power, medium power and high power.



AC 85V - 256V

•DC85V-265V Wiring-

